

I40+

Hands-free opening, enlarged print area and mobile: The perfect start to production.

The I40+ is our all-rounder for the start of production. This printer stands out as a freestanding model with a large printing area. The Automatic Separation Module (ASM) enables the automated removal of parts as well as the direct start of the next print job (patent pending). The printer can be flexibly positioned and moved on its rollers.

Performance parameters	I40+
Building area	231 × 130 mm
Native pixel	+/- 30 μm
Max. part height	250 mm (with ASM: 80 mm)
Light source	Power UV LED
Resolution	4K 3840 × 2160 px
Dimension (W × H × D)	600 × 1660 × 570 mm
Connections	WLAN, TCP/IP, USB
Control	10" LCD-Display, Touch-Screen



Large printing area

Solid glass reservoir temperature adjustable

Hands-free opening

Flexible positioning

Certified auto calibration (ACCS)

Emergency Shut-off, optional exhaust air connection

RFID to support workflow management

Knowledge Center Access



Automatic separation module (ASM)



Open System



High safety standards