

RS wash

rapidshape

For the perfect finish of your components – Automated and environmentally friendly cleaning

The RS wash automatic cleaning system excels thanks to its simple operation and process-controlled connection to your printer, for professional and validated post-processing of your printed parts. In combination with the stackable RS cure, it offers a simple and validated workflow. Thanks to automatic selection of the appropriate cleaning program and cleaning medium, cleaning the printed parts is not only process-safe and simple, but also environmentally friendly thanks to a 2-step principle with pre-cleaning and final cleaning (patent pending). The replaceable liquid container (plug-in system) is used for easy and safe handling.



Wireless connectivity to printer



Clean process, no handling of sticky resins



Reduced smell



Small space requirement



Performance parameters	RS wash
Volume	130 x 75 x 60 mm
Cleaning time	approx 6-10 minutes (depending on material)
Cleaning medium	Isopropanol, ethanol
Dimension (W x H x D)	230 x 270 x 380 mm
Connection	WLAN/LAN